



Steps for easy extraction:

- 1) Spread the tool legs so as to widen the two extraction tongs.
- 2) Insert the extraction tongs into the slots of the PLCC socket.
- 3) Place thumb and fingers on the ribbed area of the tool. Push downward slightly to keep the tool butted on the socket. Squeeze the thumb and fingers together so that the two legs tend to straighten. Pull upward and the chip carrier is removed from the socket.