

A = .100 [2.54] X No. of Positions / 2 + .300 [7.62]
 B = .100 [2.54] X No. of Positions / 2 + .200 [5.08]
 C = .100 [2.54] X No. of Spaces

BHR
STRAIGHT PCB MOUNT

BHR-34-VUA

A = .100 [2.54] X No. of Positions / 2 + .300 [7.62]
 B = .100 [2.54] X No. of Positions / 2 + .200 [5.08]
 C = .100 [2.54] X No. of Spaces

BHR
RIGHT ANGLE PCB MOUNT

BHR-34-HUA

A = .100 [2.54] X No. of Positions / 2 + .300 [7.62]
 B = .100 [2.54] X No. of Positions / 2 + .200 [5.08]
 C = .100 [2.54] X No. of Spaces

BHR
SURFACE MOUNT

BHR-30-VSG-SMT

