

---

# Hardware Description RF Design Kit ATAK57xx

## Description

The RF Design Kit supports the development of RKE systems with Atmel's UHF FSK/ASK remote control transmitters T57xx and UHF FSK/ASK remote control receivers T57xx.

The RF Design Kit consists of a motherboard (microcontroller board), an RF receiver (receiver design board), an RF transmitter (transmitter design board), an interface board and various other components as listed below. The configuration of the RF receiver and transmitter is programmable via the PC with the RF Design Kit software. The data communication between the PC and the application boards works via the serial port (RS-232).

The various kit versions and the corresponding order numbers are listed in the separate document "Selection Guide RF Design Kit ATAK57xx".

## Design Kit Contents

- 1 Motherboard (Microcontroller Board)
- 1 Interface Board
- 1 Transmitter Design Board ATAB57xx
- 1 Receiver Design Board ATAB57xx
- 1 9-pin RS-232 Cable
- 1 DC Power Cable
- 1 Whip Antenna with BNC Connector (Male)
- 1 Lithium Battery CR2032
- 1 PCB Jack for Transmitter Design Board (Used to Supply the Transmitter IC from Battery)
- 1 Adapter SMB (Female) to BNC (Female)
- 1 Atmel CD-ROM "Software/Documentation"
- 1 Atmel CD-ROM "Products"

Please bear in mind that the components provided with the RF Design Kit, as illustrated in Figure 1 on page 2, may look slightly different for the various kits.



---

## ATAK57xx Hardware Description

---

## Application Note

## Preliminary

Rev. 4718A-RKE-11/03



**Figure 1. Kit Contents**



## Motherboard


### Features

- Flexibility to Operate Various Transmitter and Receiver Design Boards
- 12 V DC Power Supply with Short-circuit Protection
- RS-232 Connector
- Power-on Switch
- Plug-in Connector for DC Power Cable
- Four Contact Strips to Connect the Interface Board and the Receiver Design Board
- LED for Power Supply Indication
- RESET Key
- LED for Sensitivity Indication
- LED for IC\_ACTIVE Indication of the Receiver
- LED for Indication of RESET and Communication over RS-232

### General Functionality

The motherboard is an AVR<sup>®</sup>-based microcontroller board which handles the data communication with the RF Design Kit software on a connected PC, the receiver design board and the transmitter design board. Its building blocks are shown in Figure 2 on page 3 and the schematic is given in Figure 3 on page 4 (only the actually assembled components are illustrated). The function of the LEDs is described in Table 1 on page 3.

**Figure 2.** Building Blocks of the Motherboard



**Table 1.** Function of the LEDs on the Motherboard


| Designator | Colour | Function   | Comment  |
|------------|--------|--|--|
| LD4        | Green  | Flashes after a RESET and during communication via RS-232  | –  |
| LD5        | Yellow | IC_ACTIVE of the receiver, operated inversely as LED IC_ACTIVE on the receiver design board<br>On -> Receiver inactive (sleep mode)<br>Off -> Receiver active (bit-check and receiving mode) | Depending on the programmed sleep times of the receiver this LED switches off rather quickly. Due to inertia of the human eye, this LED seems to be on though it is flashing. When increasing the sleep time, the LED emits brighter light and vice versa. |
| LD6        | Red    | Sensitivity indicator<br>On -> Full sensitivity<br>Off -> Reduced sensitivity  | –  |
| LD7        | Green  | 5 V power supply indicator for the motherboard and for the contact strips<br>On -> Voltage on<br>Off -> Voltage off  | Contact strips are used as power supply for the interface board and the receiver design board.   |



## Interface Board

The interface board (see Figure 4 on page 5) consists of a socket for programming of the transmitter design board and five LEDs for different functions as illustrated in Table 2 on page 5. For protection against short circuits, the programming socket is equipped with a polarizing key between pin 3 and pin 4.

**Figure 4.** Interface Board



**Table 2.** Function of the LEDs on Interface Board

| Designator | Color  | Function   |
|------------|--------|--|
| D1         | Blue   | On -> AVR is ready to receive data from the connected receiver<br>Flashing -> data is being received |
| D2         | Orange | Testword incorrect and microcontroller limits ok, see page 8   |
| D3         | Yellow | Microcontroller limits out of selected borders   |
| D4         | Green  | Testword ok and microcontroller limits ok, see page 8  |
| D5         | Red    | Communication via RS-232 is active   |

## Operation of the RF Design Kit

### Assembly of the Kit Components


To configure the RF transmitter or receiver, the appropriate design board must be connected to the motherboard. To prevent damaging, the interface board, the design boards must be plugged-in as shown in Figure 5 on page 6. The motherboard has to be connected to a PC via a serial port (RS-232). The configuration will be set by the RF Design Kit software.

During configuration, the AVR microcontroller on the motherboard handles the data communication with the PC, the receiver design board and the transmitter design board.

When configured, the transmitter design board operates stand-alone and can be removed.

The installation of the RF Design Kit software is explained in the separate document "ATAK57xx Software Description".

**Figure 5.** Assembly of the Components



## Starting the RF Design Kit

**Connecting the RF Design Kit** To ensure proper operation, the following steps should be carried out before starting the RF Design Kit software:

1. Insert the lithium cell into the battery holder of the transmitter design board.
2. Check that the RF Design Kit is assembled as shown in Figure 5 on page 6.
3. Connect the 9-pin RS-232 cable to an unused serial port.
4. Connect the DC power cable to a 12 V DC power supply unit (on-board 5 V regulator).
5. Switch on the 12 V DC power supply of the motherboard.
6. Switch on the PC and start the operating system.
7. Press the reset button (Key RESET).
8. Start the RF Design Kit software with the command: *RF-Designkit.exe*

## Programming of the Transmitter Design Board

1. Remove the PCB jack from the transmitter design board.
2. Plug the transmitter design board into the socket on the interface board.
3. Program the desired settings via the RF Design Kit software.
4. Remove the transmitter design board from the socket of the interface board.
5. Plug-in the PCB jack to supply the transmitter IC from battery.
6. The transmitter design board can now be operated in stand-alone.

## Programming of the Receiver Design Board


The receiver design board operates only in conjunction with the motherboard, hence proceed as follows:

1. Switch off the power supply of the motherboard.
2. Plug the receiver design board into the contact strips as shown in Figure 5 on page 6.
3. Switch on the power supply of the motherboard.
4. Program the desired settings via the RF Design Kit software.

## Principle Function

After power on, the AVR microcontroller on the motherboard configures the RF receiver. The receiver is then in polling mode and verifies the presence of a valid transmitter signal. The parameters for the bit-check ( $BR\_Range$ ,  $N_{bitcheck}$ ,  $T_{sleep}$ ,  $Lim\_min$ ,  $Lim\_max$ ) are programmable with the RF Design Kit software. If a valid transmitter signal is detected, the receiver remains active and transfers the data stream to the connected AVR microcontroller on the motherboard.

Figure 6. Principle Function



The AVR microcontroller continuously measures the time between two signal edges (= 1 sample). If the time  $t \geq 1/\text{baud rate}$ , the following 64 samples will be stored in the RAM of the microcontroller (start of measurement/end of measurement, see Figure 6 on page 7). Then, the RF receiver will be set back to polling mode by the microcontroller pulling pin DATA to '0' for a time  $t_1$ . The timing limits of  $1/\text{baud rate}$  are programmable in the RF Design Kit software.

The 64 samples will be examined by means of the microcontroller to distinguish between a valid signal from a corresponding transmitter and signals due to noise. This is done by a time frame check where the samples are continuously compared to a programmable time window ( $\mu\text{C\_Limits}$ ).

If the samples are within the time window and the received data stream is equal to a programmable testword (Testword), this will be indicated by the LED D4 on the interface board. After the evaluation of the received data stream, the RF receiver will set back to polling mode.

The timing information (64 samples) also can be evaluated with the functions "Testword", "Histogram" and "Timing\_List" in the RF Design Kit software menu.



## Atmel Corporation

2325 Orchard Parkway  
San Jose, CA 95131, USA  
Tel: 1(408) 441-0311  
Fax: 1(408) 487-2600

## Regional Headquarters

### Europe

Atmel Sarl  
Route des Arsenalux 41  
Case Postale 80  
CH-1705 Fribourg  
Switzerland  
Tel: (41) 26-426-5555  
Fax: (41) 26-426-5500

### Asia

Room 1219  
Chinachem Golden Plaza  
77 Mody Road Tsimshatsui  
East Kowloon  
Hong Kong  
Tel: (852) 2721-9778  
Fax: (852) 2722-1369

### Japan

9F, Tonetsu Shinkawa Bldg.  
1-24-8 Shinkawa  
Chuo-ku, Tokyo 104-0033  
Japan  
Tel: (81) 3-3523-3551  
Fax: (81) 3-3523-7581

## Atmel Operations

### Memory

2325 Orchard Parkway  
San Jose, CA 95131, USA  
Tel: 1(408) 441-0311  
Fax: 1(408) 436-4314

### Microcontrollers

2325 Orchard Parkway  
San Jose, CA 95131, USA  
Tel: 1(408) 441-0311  
Fax: 1(408) 436-4314

La Chantrerie  
BP 70602  
44306 Nantes Cedex 3, France  
Tel: (33) 2-40-18-18-18  
Fax: (33) 2-40-18-19-60

### ASIC/ASSP/Smart Cards

Zone Industrielle  
13106 Rousset Cedex, France  
Tel: (33) 4-42-53-60-00  
Fax: (33) 4-42-53-60-01

1150 East Cheyenne Mtn. Blvd.  
Colorado Springs, CO 80906, USA  
Tel: 1(719) 576-3300  
Fax: 1(719) 540-1759

Scottish Enterprise Technology Park  
Maxwell Building  
East Kilbride G75 0QR, Scotland  
Tel: (44) 1355-803-000  
Fax: (44) 1355-242-743

### RF/Automotive

Theresienstrasse 2  
Postfach 3535  
74025 Heilbronn, Germany  
Tel: (49) 71-31-67-0  
Fax: (49) 71-31-67-2340

1150 East Cheyenne Mtn. Blvd.  
Colorado Springs, CO 80906, USA  
Tel: 1(719) 576-3300  
Fax: 1(719) 540-1759

### Biometrics/Imaging/Hi-Rel MPU/ High Speed Converters/RF Datacom

Avenue de Rochepleine  
BP 123  
38521 Saint-Egreve Cedex, France  
Tel: (33) 4-76-58-30-00  
Fax: (33) 4-76-58-34-80

---

### Literature Requests

[www.atmel.com/literature](http://www.atmel.com/literature)

**Disclaimer:** Atmel Corporation makes no warranty for the use of its products, other than those expressly contained in the Company's standard warranty which is detailed in Atmel's Terms and Conditions located on the Company's web site. The Company assumes no responsibility for any errors which may appear in this document, reserves the right to change devices or specifications detailed herein at any time without notice, and does not make any commitment to update the information contained herein. No licenses to patents or other intellectual property of Atmel are granted by the Company in connection with the sale of Atmel products, expressly or by implication. Atmel's products are not authorized for use as critical components in life support devices or systems.

© Atmel Corporation 2003. All rights reserved.

Atmel® and combinations thereof, and AVR® are the registered trademarks of Atmel Corporation or its subsidiaries.

Other terms and product names may be the trademarks of others.



Printed on recycled paper.

4718A-RKE-11/03